

HINGE OFFSET: HOW TO MEASURE



Measure the distance from the bottom & top of the cabinet to the **MIDDLE** of the bore hole.
Standard is 3" offset.