

You have these conditions:



**Existing Door
or No Door
Over 63"**



**Framed
Cabinet**

NOTE 1: Our maximum door size height is 63", for sizes larger you will need to order 2 doors.

NOTE 2: Your doors will be attached together using our mending kit.



Determine your door front sizes:

- Download our helpful form to record your information the same way our website will ask for it. [Measurement Form](#)
- Calculate your hinge overlay** using the formula on the right to determine if it's one of the Available Hinge Overlays.

If your hinge overlay is any of the Available Hinge Overlays:

- Measure your existing door to the closest 1/16" (0.0625"). Measure width first, then height.
- Divide the height into 2 doors less than 63" each.

If your hinge overlay is not any of the Available Hinge Overlays or you have No Door, we suggest you use a 1/2" overlay on your replacement door:

- Measure your cabinet opening to the closest 1/16" (0.0625").
- Add 1" to the cabinet opening width and to the opening height.
- Divide the height into 2 doors less than 63" each.

- Write the dimensions of the doors you need on the measurement form.

Calculate Your Hinge Overlay	
$\frac{\left(\text{Door Width}\right) - \left(\text{Opening Width}\right)}{2} =$	
Available Hinge Overlays	
1/2"	0.5"
3/4"	0.75"
1"	1.00"
1-1/4"	1.25"
1-3/8"	1.375"



What to order:

- Order 2 doors to cover opening with the dimensions determined above.
- Order the accessory item: **"I-O295 Mending Plate to Join Doors, with Screws."**

We're here to make it easy. Call: 844-MY-DIY-KIT | Support@KitchenMakeover.com