


To properly measure your cabinet doors and drawer fronts, you just need to learn **THREE** things.


- 1 Tell the difference between a **FRAMED** and a **FRAMELESS CABINET**.
- 2 Determine the **HINGE OVERLAY**.
- 3 How to **MEASURE THE EXISTING DOORS**.

1 ARE THE CABINETS FRAMED OR FRAMELESS?

THERE ARE 2 WAYS TO VISUALLY ANSWER THIS.



A. Confirm there is a wood face frame.



B. Determine how the current doors are hinged.


2 WHAT IS THE HINGE OVERLAY?

HINGE OVERLAY IS THE AMOUNT A CABINET DOOR COVERS EACH SIDE OF THE WOODEN FRAME ON THE FRONT OF A CABINET.


FOR FRAMED CABINETS:

$$\frac{(\text{Door Width}) - (\text{Cabinet Opening Width})}{2} = \text{HINGE OVERLAY}$$

FOR FRAMELESS CABINETS: ALWAYS FULL OVERLAY
JUST MEASURE YOUR END PANEL, TYPICALLY IT'S EITHER 5/8" OR 3/4".



1/2" OVERLAY DOOR EXAMPLE



3 HOW DO I MEASURE MY EXISTING DOORS?

MEASURE WIDTHS AND HEIGHTS OF EXISTING DOORS AND DRAWERS TO THE CLOSEST 1/16".

FOR THESE EXCEPTIONS: No Doors Present, Lazy Susan or Non-Standard Hinges see our Advanced Measuring Techniques.